
Remote Station Reboot Box (RBX)


User Guide v0



Justin S. Ball
University of Colorado at Boulder
3/26/18

System Overview

Normally-Closed Relay Module



Arduino Uno R3 with RS232 Shield for Serial Connection to Cell Modem RBX Inserts Between
Battery and Power
Box to Interrupt
Station Power upon
Remote Command

Hardware Installation


1. Connect RBX's RS232 port to modem's serial port using null-modem cable with all flow control lines disconnected.



- 2. Connect top row red and black terminals to pos/neg posts of main station battery
- 3. Connect station power box positive input to bottom red terminal, and power box negative to the common (black) terminal at top right


Hardware Installation (Block Diagram)

(Block Diagram)



Modem Setup

1. To enable your modem to pass incoming UDP data through its serial port, just log into your modem's firmware on AceManager, go to the "Serial" tab and set parameters as follows. Then hit "Apply":



Using the Box to Reboot a Station

 To reboot a station, simply send the hex byte "8C" (140 in decimal) to UDP port 5380 of the modem. On the bash terminal of any Mac you can do it like this:

```
terminal Shell Edit View Window Help

admin = justin@biho-biho: /home/justin = biho-biho = -bash = 109×36

[Admins = MacBook = Air: ~ admin$

[Admins = MacBook = Air: ~ admin$
```

The "-e" flag tells echo to interpret "\x8C" as a hex byte, which tells the RBX it's time to reboot your station.

2. Once you have sent the reboot command to the modem, the RBX will power off the entire station for 1 minute before powering it back on. To check to see if the RBX has done this, try pinging the modem IP address immediately. You should see no response for about 2 minutes:

```
Admins-MacBook-Air:~ admin$ ping 166.

PING 166. (166. ): 56 data bytes

Request timeout for icmp_seq 0

Request timeout for icmp_seq 1

Request timeout for icmp_seq 2

Request timeout for icmp seq 3
```

3. Once the whole station has successfully rebooted after 3-5min, you should again see a ping response from the modem, and data should begin telemetering from the Reftek to your server:

```
PING turner-tis.map.rastly.net (151.101.49.67): 56 data bytes 64 bytes from 151.101.49.67: icmp_seq=0 ttl=58 time=50.432 ms 64 bytes from 151.101.49.67: icmp_seq=1 ttl=58 time=55.720 ms 64 bytes from 151.101.49.67: icmp_seq=2 ttl=58 time=61.428 ms 64 bytes from 151.101.49.67: icmp_seq=3 ttl=58 time=53.530 ms
```